

Getting Started with the 2017 Thor Miramar **THIS IS A NON SMOKING/VAPING COACH**

FOR AN IN-DEPTH DESCRIPTION OF THIS COACH, FOLLOW THIS [LINK](#). IT'S A GOOD INTRODUCTION BEFORE HEADING OUT ON THE ROAD, AND CAN BE A GOOD REVIEW WHEN ON THE ROAD.

KEYS:

- Entry Door Keys (black):
 - square top - top 'deadbolt' lock
 - round bottom - bottom 'handle' lock
- Engine Key - black, longer than entry keys
- Compartment Key - purple
- Silver '751' Key - only opens TV compartment and 'water-fill' cover.
- *Loss of any keys will result in a replacement fee

ENTER RV:

- turn on the "Use" switch at the steps left of entry door
- if needed, push the **GREEN** inverter button "On"
- turn on the generator to get/keep the Air Conditioner packs cooling

ENGINE MUST BE OFF and GENERATOR ON TO OPERATE:

- slides
- over the cab loft
- awning

ENGINE MUST BE ON TO OPERATE:

- auto leveling jacks

REFRIGERATOR OPERATES WHEN:

- Coach is plugged in to shore power
- Inverter is ON while engine is running - **GREEN** inverter button is ON
- Generator is ON

OPERATING THE SLIDES-

-Slides "Breakdown" Instructions When Preparing To Travel-

- Coach Engine MUST Be Off To Operate Slides
- BE SURE THE DRIVER'S SEAT IS MOVED FORWARD OUT OF THE WAY OF THE KITCHEN TABLE SLIDE (SLIDE 1). DAMAGE TO THE DRIVER'S SEAT COULD OCCUR IF NOT
- DO A THOROUGH CHECK FOR OBJECTS AROUND ALL SLIDES AND UNDER SLIDE FURNITURE
- *OBSTRUCTIONS CAN GET STUCK AND/OR TRAPPED UNDER SLIDES CAUSING DAMAGE TO THE SLIDE/FLOOR OR CAUSE AN OPERATION MALFUNCTION
- Slide-Out Damage Will Result with Fees for Repairs***

- RETRACT SLIDES IN ONE OF THE TWO ORDERS BELOW:**
 - Push Button To RETRACT Slide 3 - bunks
 - Push Button To RETRACT Slide 2 - master BR
 - Push Button To RETRACT Slide 1 - main living area
 - Can do slide 2, 3, then 1
 - The important thing is to choose an order that keeps the Coach balanced - opposite sides

-Slides “Set-Up” Instructions When Arrive to Campsite-

- Coach Engine MUST Be Off To Operate Slides
- DO A THOROUGH CHECK FOR OBJECTS AROUND ALL SLIDES AND UNDER SLIDE FURNITURE
- *OBSTRUCTIONS CAN GET STUCK AND/OR TRAPPED UNDER SLIDES CAUSING DAMAGE TO THE SLIDE/FLOOR OR CAUSE AN OPERATION MALFUNCTION
- Slide-Out Damage Will Result with Fees for Repairs***

- EXTEND SLIDES IN ONE OF THE TWO ORDERS BELOW:**
 - Push Button To EXTEND Slide 3 - bunks
 - Push Button To EXTEND Slide 2 - master BR
 - Push Button To EXTEND Slide 1 - main living area
 - Can do slide 2, 3, then 1
 - The important thing is to choose an order that keeps the Coach balanced - opposite sides

AUTO LEVELING JACKS: - **NOTE - engine MUST be ON*

- Controller located left of driver’s seat
- If the leveling jacks are down- and you’re preparing to travel:
 - push the power-on button to the controller
 - push the retract button
 - when the message says “Jacks Up”-
 - push the power button off again
 - turn the engine off

Reminder: slides, over the cab loft, and awning will not operate if the engine is running

- To Level the Coach - meaning leveling jacks are up and need to go down once you arrive at your destination
 - all occupants should either step outside, or sit down during this process
 - push the power-on button to the controller
 - push the "Auto Level" button
 - During this process the Coach could shift up and down, and pause several times before stopping in its final position
 - *Do Not Allow The Coach Tires To Leave The Ground

INSIDE THE MIRAMAR

CAB AREA:

- Night Shade Button
- Driving Sun Shade-
 - Helps on sunny days - lowers about 18"
- Generator Button - hold to start from driver's seat
- Jacks-
 - located left of driver's seat
 - see "Leveling Jacks" section for operation
- Passenger Laptop Desk-
 - Outlet under passenger window will operate when inverter in on
 - both chairs have release levers to turn to become seating area
- Driver's chair doesn't turn much due to steering wheel-
 - DO NOT FORCE the chair past steering wheel
 - Pedestal table can be placed between chairs-
 - Post located in master suite closet left of TV
 - Table located under king bed
 - Over the Cab Loft - for Travel:**

-Instructions For Traveling - **IMPORTANT**

- MUST DO** - Remove Extra Memory Foam Mattress
 - Return To Its Travel Location either on:
 - king bed OR bunk bed
- Use Power Switch to Return Bunk to Ceiling
- Secure Bunk by Placing Pins in Holes
 - You Will Hear it Click into Place
- DO NOT TRAVEL WITH PINS OUT
- DO NOT TRAVEL WITH LOFT BED DOWN
- Damage/Repair Fee Could Be Charged If Not Followed**

OVER THE CAB LOFT - for Set Up:

-Instructions for Use When Set Up at Campsite:

- REMOVE PINS **BEFORE** OPERATING POWER SWITCH
- Power Switch Located in Cabinet Above Entry Door
- Will ONLY Operate when the Coach Engine Is **Off**
- The Bed Will Stop When it Reaches Lowest Position
- Place Extra Memory Foam Mattress on Top of Existing Mattress-
 - located either on the king bed or bunk bed

DINETTE:

- Storage Drawer Pulls Out From Right Side Bench ONLY
- Makes Into a Bed, However the Table is Tempermental, therefore Not Recommended
- Has seat belts

KITCHEN:

- Sink Cover Storage Slot Under Sink
- Gas Stove and Oven-
 - Oven Must Be Lit from Inside
- Residential Refrigerator-
 - Runs on Inverter While Traveling Down Road-
 - Green Light Indicator Left of Entry Steps at Floor Level Means Inverter is On
 - Runs on Electric Power at Campsite when Plugged In
 - Runs on Generator if Not Plugged in at a Campsite
- Storage
 - Above Theater Seats
 - Above Sink
 - Pantry - located right side of refrigerator
 - Drawers

THEATRE SEATING/TV/FIREPLACE:

- Seats Recline
 - release pull lever is between armrests and seat cushion
 - TV Pulls Out for Better Viewing
 - pull black T release handle behind TV to adjust
 - Blu Ray Player Above Microwave
 - DVDs in Armrest of Theater Seats for Your Viewing Pleasure
 - Fireplace Provides Ambiance and/or Some Heat (all electric)

BUNK HOUSE:

- Zippered Mattress Protectors Provided
- Bunk Light, TV with remote

MID-SHIP and MASTER SUITE BATHROOMS:

- MUST USE RV TOILET PAPER ONLY
 - Using Anything Else Could Result in Damage/Repair Fee**
 - A Few Rolls Have Been Provided
 - Can Be Purchased at Walmart in the RV Section
- Foot-Pedal Flush

MASTER SUITE:

- King Size Bed - zippered mattress protector provided
- TV
- Bluetooth Radio
- Storage
 - Closets and Drawers
 - Cabinets Above The Bed
- Extra Memory Foam Mattress
 - This is for the Over the Cab Loft
 - If You Don't Intend to use the Loft Space You may want to Store the Mattress in the Loft out of the way
 - Follow the Instructions for Operating the Over the Cab Loft to Store the Extra Mattress in this Space

Returning the Coach

- Place All Linens and all Rugs in Trash Bag/s
- Refrigerator/Freezer Empty and Wiped Clean
- Ice Maker in OFF position - lever up
- All Cabinets and Drawers Empty and Wiped Clean
- All Utensils Clean
- Kitchen Sink, Counters, and Table Disinfected and Clean
- Bathroom Sinks, Counters, and Toilets Disinfected and Clean
- Floor Swept and Swiffer Mopped
- CHECK ALL AREAS FOR PERSONAL ITEMS-
 - Under mattresses/between mattresses and walls
 - Between furniture cushions

If Pets Traveled With You

- No Visible Pet Hair or Pet Dirt
 - An Additional Cleaning Fee WILL Be Assessed if Pet Hair and Dirt are Found After Returning the Coach
- A Damage Fee Will Be Assessed if Your Pet Damages:
 - Screens on Windows or Door
 - Cushions
 - Mattresses
 - Furniture
 - Cabinets
 - Floor

**IF THE COACH IS NOT RETURNED IN THE SAME CONDITION
IT WAS RECEIVED, ADDITIONAL CLEANING FEES
FROM \$100- \$250 WILL BE ASSESSED**

THERE IS NO SMOKING IN THIS COACH

***IF CIGARETTE, CIGAR, OR VAPE SMELL REMOVAL IS NEEDED
IT WILL RESULT IN A \$200-\$1000 CLEANING CHARGE**

DEPARTURE WALK-AROUND CHECKLIST

OUTSIDE:

- Verify Awning is retracted
- Verify Leveling jacks are actually up
- Verify ALL Slides are actually in
- Surge protector removed from campsite pedestal and returned to power cord compartment
 - \$200 fee if Coach is returned without the surge protector
- Power cord coiled up and stored in compartment
 - \$250 fee if Coach is returned without the power cord
- Water hoses coiled up and returned to Water Bay compartment
 - \$20 fee, per hose, if Coach is returned without the hose/hoses
- Black Tank Dumped-
 - \$50 Fee per tank, if not done
- Black Tank Dump Equipment left in clean condition
- Compartment doors securely latched and locked

INSIDE:

- Countertops clear of loose objects for safety
- Cabinet doors securely shut
- Shower doors securely latched
- Toilet lids down
- Slides in
- For Additional Inside Information, Refer to the Cleaning Requirements Page for Detailed Returning Expectations*

You are now ready to depart and go have fun!
If you ever get stuck, or have any questions about anything,
I will have my phone with me at all times. Thank You, Again!!

Rodney & Andrea Morrow
765-881-2192